<u>Assignment - 5</u>

Configuration of DHCP connection.

Procedure:


Step 1: Take a Router, a Switch, one PC and one Laptop

Step 2: Connect Switch with Router and connect the PC and Laptop with

Copper Stright-Through wire.

Step 3: Enable the port of the Router where the Switch is connected

Step 4: Assigning an class-C IP Address to the Router:




Step 4: After that open CLI of Router and write these commands one by one by hitting enter.


```
Router(config-if) #ip dhcp pool mypool
Router(dhcp-config) #network 192.168.0.0 255.255.255.0
Router(dhcp-config) #default-router 192.168.0.1
```

Step 5: Now open IP Config of PC & Laptop by double clicking on PC & Laptop


Icon select the DHCP option then you can see PC or Laptop requesting

IP from DHCP server and show the allotted IP Address.





❖ <u>Diagram</u>:



❖ Output's:

```
C:\>ping 192.168.0.1

Pinging 192.168.0.1 with 32 bytes of data:

Reply from 192.168.0.1: bytes=32 time<1ms TTL=255
Reply from 192.168.0.1: bytes=32 time<1ms TTL=255
Reply from 192.168.0.1: bytes=32 time<1ms TTL=255
Reply from 192.168.0.1: bytes=32 time=6ms TTL=255
Reply from 192.168.0.1: bytes=32 time=6ms TTL=255

Ping statistics for 192.168.0.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 6ms, Average = 1ms</pre>
```

Response coming from Router when ping Router IP in CMD, So DHCP connection I successful.